

SPEED-FLO SPOUT INSTRUCTIONS



1

Step 1: Squeeze tab and twist off black screw cap (counter-clockwise) to remove spout.




3a

Step 3: a) Using the black screw cap, insert spout through cap. Tighten cap (clockwise) and spout onto the can. Remove red dust cap.



4

Step 4: Before use: Place on flat surface and click in red safety lock. This will un-lock your spout for use.



2

Step 2: Remove spout from container and pull off storage cap. Set storage cap aside for future storage.



3b

b) Vent before using. To vent: Slowly loosen black screw cap until you hear pressure release. After venting, re-tighten cap and spout before use.



5

Step 5: To use: Place tip of spout inside tank. rest notch on tank lip, push downward to retract spout. This will start flow.

Remember to click in red safety lock before each use. When using, never point at yourself or anyone else.